

	12308 Nebezpečí výbuchu! 9903 0001 99 999		12333 Nebezpečí výbuchu plynu! 9903 0002 99 999		12338 Nebezpečí otravy plynem! 9903 0003 99 999		12345 Nebezpečí uklouznutí! 9903 0005 99 999		12335 Nebezpečí úrazu! 9903 0007 99 999
	12311 Pozor! Nahoře se pracuje 9903 0004 99 999		12312 Pozor schod! 9903 0006 99 999		12302 Pozor! Napětí životu nebezpečné 9903 0015 99 999		12301 Pozor! Elektrické zařízení 9903 0014 99 999		12362 Pozor! Tlakové láhve 9903 0037 99 999
	12339 Nebezpečí popálení 9903 0036 99 999		13032 Nebezpečí střetu s vozíkem 9903 0039 99 999		12356 Jeřáb dálkově ovládan 9903 0038 99 999		12302 Vysoké napětí, životu nebezpečno dotýkat se el. zařízení! 9903 0015 99 999		12672 Zákaz vstupu s plamenem! 9903 0020 99 999
	12119 Zákaz kouření a vstupu s plamenem! 9903 0009 99 999		12111 Vstup zakázán 9903 0011 99 999		12318 Zákaz kouření 9903 0008 99 999		12109 Nehas vodou ani pěnovými přístroji! 9903 0010 99 999		12115 Nepovolaným vstup zakázán! 9903 0012 99 999
	12103 Nezapínej! Na zařízení se pracuje! 9903 0016 99 999		12142 Zákaz parkování 9903 0023 99 999		12128 Vstup na staveniště zakázán! 9903 0034 99 999		12126 Kotelna Nepovolaným vstup zakázán! 9903 0045 99 999		12517 Hasicí přístroj 9903 0021 99 999
	12721 Pozor - Objekt strážěn psy! 9903 0022 99 999		12751 Chodci přejděte! 9903 0035 99 999		12179 Spotřebiči povolen 9903 0032 99 999		12276 Kouření zakázáno 9903 0031 99 999		12736 Mimo provoz! 9903 0030 99 999
	12437 Pitná voda 9903 0029 99 999		12205 Pracuj v ochranné přilbě! 9903 0041 99 999		12226 Používej ochranné rukavice! 9903 0043 99 999		12221 Používej respirátor proti prachu! 9903 0040 99 999		12206 Pracuj jen v ochranných brýlích! 9903 0042 99 999
	12223 Používej chrániče sluchu 9903 0044 99 999		12671 Hlavní vypínač Vypni v nebezpečí! 9903 0019 99 999		12405 První pomoc 9903 0013 99 999		12404 Hlavní vypínač 9903 0017 99 999		12514 Bezpečnostní šípka 9903 0024 99 999
	12512 Únikový východ 9903 0026 99 999		12433 Hlavní uzávěr plynu 9903 0027 99 999		12434 Hlavní uzávěr vody 9903 0028 99 999		12432 Východ 9903 0025 99 999		12435 Hlavní uzávěr 9903 0033 99 999